ASCENT GOGGLES

Quick Start Guide

V1.0

Introduction

This product is a wireless image transmission head-mounted display device, compatible with *Ascent HD System* series air unit products, and can achieve long-distance, low-latency, high-definition wireless image transmission. In the document, the terms *VTX, Air unit, etc.* refer to Ascent image transmission series products. In the document, the terms *Goggles, VRX, Goggles, etc.* refer to Ascent image transmission display products.

1. Built-in Antenna
2. Link Button
   (Short press to enter the linking state, long press for 8 seconds to enter the upgrade state)
3. Power Button
   (Short press to start or stop video recording)
4. Up Button
   (Press to return to the previous menu or exit the current mode)
5. SD Button
   (Toggle the button to scroll through the menu. Press the button to confirm)
6. Power Port
   (Voltage range: 6V~25.2V, DC 5.5*2.1)
7. Micro SD Card Slot
8. Frame Mounting Holes

Linking

1. Connect the VTX and the power of the Goggles.
2. Set the channel, BW, GI, MCS, and power respectively (as shown in the picture), when the VRX enters the pairing state (The indicator light turns red, and the Goggles emit a di Di... Di...).
   After the link is successful, the indicator light on the VTX turns solid green, the beeping sound on the Goggles stops and the screen is displayed.

Upgrade

Please go to the official website to download the upgrade firmware, Ascent_(...)_Goggles_X_X.img is the firmware file, copy it to the SD card, be careful not to change the file name.

1. Close the upgrade file to the root directory of the SD card, connect to the power supply and wait for the device to initialize (Approximately the first 8 seconds).
2. Press and hold the link button on the Goggles for 8 seconds, and the Goggles will enter the upgrade state (the indicator light flashes red).
   Do not power off during the upgrade process, the upgrade time on the goggle is about 1 minutes!
3. After the upgrade is successful,and the beeping sound stops after the Goggles beep for 5 seconds.

Status indication

Goggles Buzzer Status	
Link state	Di... Di... Di... Di...
Upgrade firmware	Di... Di... Di... Di~~~~
Upgrade failed (No SD card or firmware detected)	Di. Di. Di. Di.
Boot failure (Reboot or re-upgrade)	Di. Di.... Di. Di....

Precautions

1. This is a professional product. Failure to operate this product in a safe and responsible manner could result in injury or damage to the product or other property. It must be operated with caution and common sense and requires some basic mechanical knowledge.
2. The transmit power of VTX and Goggles is only 10mW when the standby mode is on.
3. There are up to three channels for the goggles depending on the region. Bandwidth of 10MHz and 20MHz.
4. It is recommended to upgrade VTX and Goggles to the latest firmware before first use.

Operating channel

Control Frequency (Fixed Channel)	Channel1	Channel2	Channel3
FCC	5740	5770	5805
CE/SRRC	5740	5770	5805

Make sure you fully understand and abide by local laws and regulations before using this product.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into a outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) Information:

This Ascent Goggles complies with government requirements for exposure to radio waves. The guideline is based on standards that were developed by independent scientific organizations through regular and thorough evaluation of scientific studies. These standards include a substantial safety margin designed to ensure the safety of all individuals, regardless of age and health.

FCC RF Exposure Information and Statement:

The SAR limit set by the FCC is of 1.6W/kg averaged over one gram of body tissue, and 4.0 W/kg averaged over 10 grams for extremities. Device tested by SAR: 0.912 W/kg. This device was tested for compliance with these SAR limits. During product certification, the highest reported SAR was found to be 0.912 W/kg for the body, and 0.139W/kg for extremities. This device has been tested for typical body operations with the back of the goggles kept 0 mm from the body. To maintain compliance with FCC RF exposure requirements, accessories that maintain a 0 mm separation distance between the user's body and the back of the goggles are used. Belt clips, holsters, and similar accessories used with this device should not contain metallic components. Accessories not meeting these requirements may not comply with FCC RF exposure requirements and should be avoided.

Body-Worn Operation:

This device has been tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 0 mm must be maintained between the user's body and the Goggles (including antenna). Third-party belt clips, holsters, and similar accessories used with this device must not contain any metallic components. Accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or approved antenna.

Software interface

Main interface~1

1-VTX input voltage:
Detect VTX voltage, intelligently identify the voltage of 2, 3, 4, 6 string LiPo batteries, alarm when a single-battery is lower than 2.5V, and alarm in red font when the voltage is too low.

2-Goggles input voltage:
Detect Goggles low battery alarm, intelligently identify the voltage of 2, 3, 4, 6 string LiPo batteries, alarm when a single-battery is lower than 3.5V, red font and buzzer alarm when the voltage is too low.

3-Real-time SD card status:
Display real-time transmission bitrate in Mbps, with 10.0M and 20.0M bandwidth modes.

4-Time delay:
Displays the total delay from the transmission of images captured by the VTX camera to the ground end.

5-Ranging mode:
The function of calculating the transmission distance from Goggles to VTX according to the wireless transmission device, the signal is intertwined with lead to error amplification.

6-Status prompt:
The text prompts information that needs attention in the current state.

7-Current channel:
Display the current setting channel, the signal grid has 5 states, 4 grids, 3 grids, 2 grid, and blank.

8-Goggles SD card status:
Display the status and remaining capacity of the Goggles SD card. When recording, the red circle flashes to prompt, the status of the SD card not inserted, the SD card is full, and the status of the memory is full is displayed.

9-Remote Controller Signal Status:
There are five signal bar states: 4 bars, 3 bars, 2 bars, 1 bar, and no bar. When no remote controller signal is detected by the image transmission module, this icon will be hidden.

Menu Channel~2

1-Channel:
Displays the interference status of each channel. Signal strength is shown as 4 bars, 3 bars, 2 bars, 1 bar, or empty. An empty signal bar indicates the channel is occupied and cannot be selected. A white outline represents the selection box. Press the confirm button to highlight a channel, and the highlighted one is the current channel.

2-Frequency Hopping:
When frequency hopping is enabled, the goggles will automatically select the channel with the least interference. Manual channel switching is not available in this mode.

3-Refresh:
Click Refresh to re-scan all channels and update their interference status.

Menu Settings~4

1-Camera:
The adjustable contents of the camera are scene preset, EV value, saturation, sharpness, white balance, rotate, ratio, 3D DNR, Diffuser, and Max ISOsetting.

2-Display:
Display adjustable content is Debug, brightness, focalization mode, custom OSD, OSD position, font upgrade, custom font, viewfinder, viewfinder edit settings.

3-Refresh set:
The refresh rate can be adjusted as VTX REC resolution, REC device, take-off REC, REC stop format SD card, reset VTX, Built-in EID, REC Time, REC Format, Color, Saturation, Sharpness.

4-Device:
Adjustable settings include Buzzer Volume, Ranging Mode, Signal Loss Alert, Restore Factory Settings, Reset VTX Defaults, Device Information, User Guide, Mode Switching, DAR Binning (goggles), and Anti-Flicker.

5-Transmission Power:
Default selection transmission power: 25 mW, 100 mW.

6-Resolution:
Selectable resolutions: 720P and 1080P.

7-Bandwidth:
Selectable 10.0M and 20.0M options for different image quality. High bitrate is only supported when FC mode is enabled.

8-Frame Rate:
The standard frame rate is equal to 60fps.

9-Standby Mode:
In standby mode,both the air unit and goggles transmit at 10 dBm. Standby mode does not allow you to return to the configured value after exiting standby mode or turning it off. This function requires the air unit to be properly connected to the flight controller via serial port--when the goggles detect an arming signal from the aircraft, standby mode exits automatically. If no flight controller is supported, this function can be disabled.

10-Language:
Language switching English/中文.

11-Battery Alarm:
Monitor the low battery status of the goggles. When voltage is too low, a red text warning and buzzer alert will be triggered. This feature can be enabled or disabled.

12.-Preferences:
Preset transmission modes: Smooth, High Quality, Long Range.

Menu Playback~5

1、The OSD switch can be turned on or off. When it is turned on, the flight control OSD information (if any) and the flight information of the main interface will be superimposed on the playing video interface. When the playback interface is in the file list, you can press the left and right buttons on the top to open the multi-selection function, and the menu box will display function settings (delete, select all , cancel), press the return key again to exit the multi-selection mode.

2、On the playback interface, click the middle button to pause/play, and the left and right arrow keys to adjust rewind/fast forward

Specifications

Name	Ascent Goggles
Communication Frequency	5.738.5-5.806.5GHz
Transmitter Power(EIRP)	FCC=20dBm, CE=14dBm, SRRC=20dBm
I/O Interface	DC5.5*2.1mm, Micro SD Card Slot
Transmission Resolution	1080p60fps, 720p60fps
Code Rate	Max 25 Mbps
Min. Latency	Average 32ms
Average Gain	4.9dBi
Polarization	LHCP
Transmission Distance	>4km
Channel	3
Screen Resolution	1920*1080,60Hz
Screen Size	LCD
Screen Size	4.5 Inch
Power Input	6V-25.2V(2S-6S)
SD card	Support 256G
System	Ascent HD system

CADDXFPV SUPPORT
email: support@caddxfpv.com

ASCENT GOGGLES

快速入门指南

V1.0

简介

该产品为无线图像传输头戴显示设备，兼容 Ascent HD System 系列天空端产品。可实现这款具低时间滞无线图像传输，支持5G模式：VTX、发射机、天空端等调试代码 Ascent 图传图像头像产品。支持5G模式：VTX、接收端、眼镜端等调试代码 Ascent 图传显示端产品。



1. 内置天线
2. 对焦键
（短按进入对焦状态，长按5秒进入升级状态）
3. 菜单键
（按下可前进/暂停录像）
4. 返回键
（按下可返回上一级菜单或当前模式）
5. 左按钮键
（上下左右控制菜单选择程方向，按下为确认或取消选择）
6. 电源接口
（电压范围 6V~25.2V，DC 5.5*2.1）
7. Micro SD卡槽
8. 镜筒安装孔

对频

1. 连接眼镜和 VTX 天空端电源。
2. 等待设备启机后，分别长按眼镜和 VTX 天空端对频按钮，当进入配对状态时，VTX 指示灯为红色，眼镜端显示为：通，通，慢速闪烁提示。
3. 对频成功后，VTX 上的指示灯变为绿色常亮，眼镜端画面将会开显示图传画面。

升级

请到官网下载最新升级固件，Ascent_L_Gnd_X_X_X.img 对应眼镜端升级固件，拷贝到眼镜端 SD 卡中，注意请勿修改文件名。

1. 将升级文件复制到眼镜端SD卡的根目录下，连接电源并等待设备启机（如果有，请先断开图传连接）。
2. 长按眼镜端对频按钮5秒后松开，即可进入升级模式，设备会自动显示升级进度条，升级完成后设备将自动重启，通，通，通，...持续时间大约为1分钟，中途请勿断电。
3. 升级成功后，眼镜端模块将自动进入对频状态，即可正常使用。

状态指示

眼镜端指示状态	
对频状态	通，通，通，通
升级固件	通，通，通，通———
升级完成（未检测到SD卡或错误）	通，通，通，通
启机失败（重启或者刷固件）	通，通，通，通

注意事项

1. 该产品使用较为复杂，使用者需具备基本的动手能力以及安全意识，并且需要小心使用。
2. 待机模式开启后飞行器未解锁 VTX 和眼镜发射功率保持于10mW。
3. 眼镜最大支持3个带宽为10MHz 和 20MHz 的频道。
4. 首次使用设置 VTX 和眼镜外部设置新固件。

工作频道

Control Frequency(MHz)	Channel1	Channel2	Channel3
FCC	5740	5770	5805
CE/SRRC	5740	5770	5805

使用本产品前，请确保您与下属并遵守当地法律法规。

FCC 警告

本设备符合 FCC 规则第 15 部分的规定。操作须遵守以下两个条件：(1) 本设备不得造成有害干扰，(2) 本设备必须接受任何收到的干扰，包括可能导致外操作的干扰。任何未经合规负责方明确批准的更改或修改都可能导致用户操作本设备的权限失效。

注意：本设备已经过测试，符合 FCC 规则第 15 部分对 B 类数字设备的限制。这些限制旨在为住宅安装提供合理的保护，防止有害干扰。本设备会产生、使用并能够辐射射频能量，如果未按照说明安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定安装中不会发生干扰。如果本设备确实对无线电或电视接收造成有害干扰（可通过关闭和打开设备来确定），则建议用户尝试通过以下一种或多种措施来纠正干扰：

- 重新调整或重新定位接收天线。
- 增加设备与接收器之间的距离。
- 将设备连接到与接收器所连接电路不同的电路插座。
- 咨询经销商或经验丰富的无线电/电视技术人员寻求帮助。

特定吸收率 (SAR) 信息：

该 Ascent Goggles 符合政府针对无线电波暴露的要求。该设备旨在基于独立科学组织通过定期和彻底的评估科学研究制定的标准。这些标准包括相当大的安全裕度，旨在确保所有人的安全，无论年龄或健康状况如何。


FCC RF 暴露信息和声明：

美国 FCC RF 暴露 (SAR) 限值是 1.6 W/kg。每个人体组织平均 4.0W/kg，设备类型：WMD2~FPL006 (FCC ID：包已针对这 SAR 限值进行了测试。

该设备以最低标称发射功率和最大 SAR 值为 0.01W/kg 测试。用于公配和组件对为 0.139W/kg。此设备已针对典型的操身戴着操作进行了测试，其中 Goggles 已经与身体保持 0mm 的距离，为了保持符合 FCC 射频暴露要求，请使用距离身体产身体和 Goggles 背面之间保持 0mm 距离的配件。使用时的发射，检查和监视操作中不应包含金属部件，使用不满足这些要求的配件可能不符合 FCC 射频暴露要求，应避免使用。

软件界面

主界面-1



1. 天空端输入电压：
显示天空端供电电压，智能识别2、3、4、6串LiPo电池电压，单片电芯低于3.5V后停止报警。

2. 地面端输入电压：
显示眼镜供电电压，智能识别2、3、4、6串LiPo电池电压，单片电芯低于3.5V后停止报警。

3. 实时码率：
显示实时传输码率单位Mbps，10.0MB2O.0MB跨发常模式。

4. 图传状态：
显示当前眼镜和天空端图传传输发电图画的总延时。

5. 频道功能：
动感无线传输延时计算接收端呈发射端传输新图画，信号越干扰信号放误差放大。

6. 时间显示：
显示当前录像时间，信号低5秒状态，4秒、3秒、2秒、1秒、空格。

7. 录像状态：
显示当前录像状态，信号低5秒状态，4秒、3秒、2秒、1秒、空格。当图传未检测到遥控器信号时，此图标会隐藏。

菜单频道-2

