AVATAR GOGGLES L

Quick Start Guide

V1.1

Introduction

This product is a wireless image transmission head-mounted display and remote control. It supports 5.8G wireless AV system series as unit products, and can achieve long-distance, low-latency, high-definition analog image transmission. In the document, the terms VTX, AV unit, etc. refer to Avatar image transmission series products. In the document, the terms VRX, Goggles, etc. refer to Avatar image transmission display products.

1. Built-in Antenna
2. Link Button
(Short press to enter the linking state, long press for 8 seconds to enter the upgrade state)
3. Record Button
(Press to start or stop video recording)
4. Back Button
(Press to return to the previous menu or exit the current mode)
5. SD Button
(Toggle the button to scroll through the menu. Press the button to confirm)
6. 3.5mm Port
7. Power Port
(Voltage range: 6V~25.2V, DC 5.5*2.1)
8. Heat dissipation outlet
9. Micro SD Card Slot

Linking

1. Connect the VTX and the power of the Goggles.
2. Press the link button of the VTX and Goggles respectively (as shown in the picture), when the VTX enters the pairing state The indicator light turns red and flashes rapidly and is in DL... DI... DI...
3. After the link is successful, the indicator light on the VTX turns solid green, the beeping sound on the Goggles stops and the screen is displayed.

Upgrade

Please go to the official website to download the upgrade firmware, Avatar_Vtx_Gnd_X.X.X.img to the Goggles file, copy it to the SD card, be careful not to change the file name.

1. Copy the upgrade file to the root directory of the SD card.
2. Insert the SD card into the Goggles, and the SD slot has to initialize (delete the all firmware file first if there is one).
3. Press and hold the link button on the Goggles for 8 seconds, and the Goggles automatically restart and emit a beep...beep...beeper sound (Do not power off during the upgrade process, the upgrade time on the goggle is about 2 minutes).
2. After the upgrade is successful,and the beeping sound stops after the Goggles beeps for 5 seconds.

Status indication

Goggles Buzzer Status	
Link state	Di... Di... Di... Di--------
Upgrade firmware	Di... Di... Di... Di------
Upgrade failed (No SD card or firmware detected)	Di.. Di.. Di.. Di..
Boot failure (Reboot or re-upgrade)	Di. Di..... Di. Di.....

Operating channel

Central Frequency (MHz)	Channel1	Channel2	Channel3
FCC	5735	5770	5805
CE/SRRC	5735	5770	5805

Make sure you fully understand and abide by local laws and regulations before using this product.

Precautions

1. This is a sophisticated product. Failure to operate this product in a safe and responsible manner could result in injury or damage to the product or other property. This product is not designed for use by children without adult supervision. Some basic mechanical knowledge.
2. The transmit power of VTX and Goggles is only 10mW when the standby mode is turned on.
3. There are up to eight channels for the goggles depending on the region (FCC: eight, CE/SRRC: four, RVR: four). Each channel has a bandwidth of 20 MHz. The public channel is 8, which is the default channel when the goggles are powered on. The channel can be changed manually to avoid interference from other devices.
4. It is not recommended to upgrade VTX and Goggles to the latest firmware before first use.

3.5mm Port Definition

1. GND
2. NC
3. Head tracking upgrade port
4. PPM (Head tracking output)

Software interface

Main interface-1

1 VTX input voltage:
Detect VTX voltage, intelligently identify the voltage of 2, 3, 4, 6 string LiPo batteries, alarm when a single battery is lower than 3.5V, and alarm in red font when the voltage is too low.

2 Goggles input voltage:
Goggles battery low battery alarm, intelligently identify the voltage of 2, 3, 4, 6 string LiPo batteries, alarm when a single battery is lower than 3.5V, red font and buzzer alarm when the voltage is too low.

3 Real-time bit rate:
Display real-time transmission code rate, two display modes of 25.0Mbps and 50.0Mbps.

4 Time delay:
Display the total delay from the transmission of images captured by the VTX camera to the ground end.

5 Ranging mode:
The function of calculating the transmission distance from Goggles to VTX according to the wireless transmission delay, the signal is interfered will lead to error amplification.

6 Status prompt:
Red text prompts information that needs attention in the current state.

7 Current channel:
Display the current setting channel, the signal grid has 5 states, 4 grids, 3 grids, 2 grids, 1 grid.

8 Goggles 5G card status:
Display the status and remaining capacity of the Goggles SD card. When inserting the SD card and flashes to prompt, the status of the SD card not detected is displayed as NO SD, and the status of the memory is full is displayed as -.

9 VTX storage status:
Display the status and remaining capacity of the VTX storage, When recording, the red circle flashes to prompt, the status of the storage not detected is displayed as NO SD, and the status of the memory is full is displayed as -.

Main interface-2

1. Display the interference situation of each channel. The signal strength is divided into 4 grids, 3 grids, 2 grids, 1 grid. The fewer the grids, the smaller the signal is occupied and cannot be selected. The white arrow is the selection box. Press the middle button to confirm the current channel and highlight it.

2、Channel working logo: When switching between standard (or rate and power) and CE (or low power), the logo will change. The CE channel cannot be selected. OFF is a public channel, which is easy to be interfered and is not recommended for flight work; Auto is a channel that automatically switches the signal interference situation of all channels. Refresh is the channel of manual refresh.

3、Channel display of each country: FCC standard displays 8 channels (CH1/2/3/4/5/6/7/R), CE/SRRC standard displays 4 channels (CH1/2/3/R), RVR standard displays 3 channels (CH1/2/R). Only in FCC mode, the high bit rate mode can be turned on, and the 8 channels become 4 channels CH1, CH3, CH5, CHR.

Share Channel-3

1、When the broadcast option is turned on in the menu settings, The VTX unique ID identifies the current VTX. Other Avatar VRX devices can receive the local image transmission through share mode.

Menu Settings-4

1-Camera:
Adjustable contents of the camera are scene preset, EV value, saturation, sharpness, white balance, rotate, ratio, 3D DNR, Shutter, and Max ISOsettings.

2-Display:
Adjustable contents are OSD position, font upgrade, custom font, viewfinder.

3-Record set:
The recordings can be adjusted as VTX REC resolution, REC device, takeoff REC, REC loop, format SD card, format VTX, Built-in EIS, REC Time, REC Folder, Color, Microphone, Screenshot.

4-Device:
The adjustable contents of the device are buzzer volume, flanging mode, Weak signal, Reset all, Device information, Instruction, and Switch mode.

5-Transmit Power:
The default transmit power can be 25mW, 200mW, 500mW, 700mW.

6-Resolution:
The resolution can choose 720P and 1080P.

7-Rate:
Standard bit rate and high bit rate can be selected to obtain different image quality, and high bit rate can only be enabled in FCC mode.

8-Frame Rate:
The standard frame rate is equal to 60fps.

9-Standby Mode:
When in standby mode, the transmission power of VTX terminal and Goggles will be reduced to 10mW, and the Goggles image transmission will be turned off. After exiting standby mode or turning off the standby mode to switch. Turning on the standby mode requires the air unit serial port to be connected correctly to the flight controller. When the goggles receive the drone's unlock signal, it will automatically exit the standby mode. If there is no flight controller support, you can choose to turn off this function.

10-Language:
Language switching English/中文.

11-Link Mode:
Detect Goggles low battery alarm, intelligently identify the voltage of 2, 3, 4, 6 string LiPo batteries, alarm when a single battery is lower than 3.5V, red font and buzzer alarm when the voltage is too low.

12-Goggle Icon:
You can choose to display or hide the icons on the main menu interface.

13-Broadcast:
After turning on the broadcast switch, others can receive your video transmission through the Avatar system. The 8 characters in brackets are the unique identification number of VTX.

Menu Playback-5

1. The OSD switch can be turned on or off. When it is turned on, the flight control OSD information (if any) and the flight information of the main interface will be superimposed on the playing video interface. When the selection box stays in the video list, press and hold the Goggles confirmation key for 2 seconds to enter/exit playback, and the menu box will display Function setting (playback, delete all, cancel), press the return key again to exit the multi-selection mode.

2、On the playback interface, click the middle button to pause/play, and the left and right arrow keys to adjust rewind/fast forward.

Specifications

Name	Goggles L
Communication Frequency	5.725~5.850GHz
Transmit Power(EIRP)	25mW/200mW/500mW/700mW
I/O Interface	Micro SD Card Slot, Nine-axis gyroscope 3.5mm Plug, DC 5.5*2.1mm
Gyro	Nine-axis gyroscope
Transmission Resolution	1080p50/60fps, 720p60fps
Code Rate	Max 50 Mbps
Min. Latency	Average 32ms
Average Gain	4.5dBi
Polarization	LHCP
Transmission Distance	>4km
Channel	3
Screen Resolution	1920*1080/90Hz
Screen Material	LCD
Screen Size	4.3 Inch
Power Input	6V~25.2V(2S~6S)
SD card	Support 256G
System	Avatar HD system

CADDXFPV SUPPORT
email: support@caddxfpv.com

AVATAR GOGGLES L

快速入门指南

V1.1

简介

GOF产品为无线图像传输头戴显示设备，兼容 Avatar HD System 系列天空端产品，可实现远距离和超高带宽无线图像传输。支持外接或一体式 VTX，安装简单，天空端等现代化 Avatar 控件摄像头保护盖，支持中频或 VTX、接收端、眼镜镜等调式代码 Avatar 固件显示保产品。



1. 内置天线
2. 对键键
（短按进入对键状态，长按6秒进入升级状态）
3. 麦克键
（短下调开始/暂停录像）
4. 返回键
（按下可返回上一级菜单或当前模式）
5. 五维按键
（上下左右控制菜单选择程序向，按下为确认或取消选择）
6. 3.5mm 接口
7. 电源接口
（电压范围: 6V-25.2V，DC 5.5*2.1）
8. 散热口
9. Micro SD卡槽

对频

1. 连接眼镜和 VTX 天空端电源。
2. 等待设备启动，分别按下眼镜和 VTX 天空端对频按钮，当进入配对状态时，VTX 指示灯变为红色，眼镜端见左图。（一共四组天约为6分钟，中途请勿断电）
3. 对频成功后，VTX 上的指示灯为绿色常亮，眼镜屏幕显示正常且图传画面。

升级

请到官网下载最新升级固件，Avatar_Lite_Gnd_X.X.X.img 对应眼镜端升级固件，拷贝到眼镜的 SD 卡中，注意请勿修改文件名。

1. 将升级文件复制到眼镜的 SD 卡的根目录下，直接将卡拷贝设备启机（如果有，请先删除旧固件文件）。
2. 长按眼镜侧对频按钮 3 秒钟眼镜将长响一秒后松开，等待设备自动重启后至出现画面提示画面：请.....请.....（升级时间大约为6分钟，中途请勿断电）
3. 升级成功后，眼镜画面将最长响3秒后停止并自动重启。

状态指示

眼镜操作画状态	
对频状态	滴、滴、滴、滴....
升级固件	滴.....滴.....滴.....滴~~~~
升级失败（未检测到SD卡或固件）	滴、滴、滴、滴....
启机失败（重启或重刷固件）	滴、滴.....滴、滴.....

Control Frequency(MHz)	Channel1	Channel2	Channel3
FCC	5735	5770	5805
CE/SRRC	5735	5770	5805

使用本产品前，请确保仅仅分厂解并遵守当地法律法规。

注意事项

1. 该产品使用较为复杂，使用者需具备基本的动手能力以及安全常识，并且需要小心使用。
2. 持机模式开启且飞行前务必将 VTX 和眼镜关机切换至静音 1~2min。
3. 眼镜具有持续 7 年使用为20 Min 的机械 和电子 的使用寿命有效年限，FCC 与 CE/SRRC 4、MIC 3），并和CP为公共频道，设备只应后台先进入该频道，用户可手动选择其他工作频道以避免设备的干扰。
4. 首次使用或设备 VTX 和眼镜并应前重新调件。

AV-IN 端口定义



软件界面

主界面-1



1. 天空端输入电压
显示天空端供电电压，智能识别2、3、4、6串LiPo电芯电压，单片电芯低于3.5V后作为报警电压。

2. 地面端输入电压：
显示眼镜供电电压，智能识别2、3、4、6串LiPo电芯电压，单片电芯低于3.5V后作为报警电压。

3. 实时码率
显示实时传输码率单位Mbps，25.0Mbps和50.0Mbps两种显示模式。

4. 录像状态：
仅插入有效存储延时计算接收端及发射端传输距离功能，仅传输卡托处会将数据保存。

5. 状态提示：
文字提示当前所处的状态提示。

6. 当前频道：
显示当前设置频道，信号格共5种状态，4格、3格、2格、1格、空格。

7. 地面端SD卡状态：
显示眼镜内存卡状态及剩余容量，录像时红圈闪烁提示，不在录制状态不显示红圈，地面卡到内存状态显示为NO SD，卡满状态显示为~。

8. 天空端内存状态：
显示天空端内存状态及剩余容量，录像时红圈闪烁提示，不在录制状态不显示红圈，地面卡到内存状态显示为NO SD，卡满状态显示为~。

菜单频道-2



1. 显示当前选中手机情况，信号强度分为4格、3格、2格、1格、空格，信号显示空格为已经成为不可选，白色显示为选择框，按下确认键将高显示，高亮显示为当前频道。

2. 频道工作频道，标准频率和高带宽功能对应当前当前频道设置为 CH* 需重新选择频道，CH* 为公共频道容易被干扰不建议*为工作频率。Auto 开关为自动跳频全频道信号干扰情况，Refresh 为手动跳频。

3. 频率频道显示，FCC 标准显示为5个频道CH1/2/3/4/5/6/7/CH1/2/3/FC/SRRC 标准显示 4个CH1/2/3/4/5，MIC 标准显示5个CH1/2/3/5，仅限 FCC 模式可开启高带频道，且5个频道至少4频道 CH1、CH2、CH3、CH*。

分享频道-3



1. 在菜单设置中开启广播选项时 ，将号内显 VTX 唯一ID号码。其他 Avatar 地面端设备可以通过分享模式接收到本机的图传画面。

菜单设置-4



1-Camera：
设置相机内容分别为传感器预设，曝光，饱和度，锐度，白平衡，画面旋转，画面比例，3D降噪，快门，基准反转，图像模式设置。

2-Display：
显示可调整内容为 Debug，屏幕亮度，聚焦模式，自定义OSD，OSD位置，升级字体，自定义字体，取景框，取景框设置。

3-Record set：
录像可调整内容为 VTX 发射端分辨率，录像设备，自动启停，循环录制，格式化SD卡，格式化发射端，内置已启动码，录像时间，录像格式，颜色，加和框，锐度。

4-Device：
设置可调整内容为操纵器设备，测距模式，信号丢失提示，恢复出厂设置，设备信息，固件信息，切换模式，。

5-Transmit Power：
发射功率默认可选择25mW，200mW，500mW，700mW功率。

6-Resolution：
分辨率可以选择720P和1080P。

7-Bitrate：
可选择比特率和采样率获得不同图像质量，高码率文件会在FCC模式开启。

8-Frame Rate：
标准帧率等于60fps。

9-Standby Mode：
当处于待机模式时天空端和眼镜端发射功率为10dbm，退出待机模式或关闭待机模式开关子会输出当前设置的发射功率，开启待机模式时此功能需要天空端保证正确连接下对应眼镜端的下行数据时候等待自动退出待机模式，如无下载则可选择关闭或功能。

10-Language：
语言切换Englsh/中文。

11-Low Battery：
检测眼镜端电量警报，电压过低红色字体和眼镜箱报警提示，可选择开启或关闭。

12-Goggle Icon：
可选择屏幕主界面图标显示或隐藏。

13-Broadcast：
当开启广播开关后，您的图传画面将可以被他人搜索到，就与内分字符为VTX 天空端唯一识别号。

菜单回放-5



1. 选择模拟动到SD或选择可以选择打开或关闭，打开时在播放视频界面叠加飞控OSD信息(如有)和光界面飞行信息，当选择模拟叠在视频的表中，长按眼镜键确认键打开主功能，菜单项显示功能设置（删除，全选，取消），再次按下返回键退出主选模式。

2. 播放界面单击中键暂停/播放，左右方向键调整快进/快退

规格参数

名称	Goggles L
通信频率	5.725-5.850GHz
发射功率(EIRP)	FCC<30dBm,CE<14dBm,SRRC<20dBm,MIC<25dBm
接口	4Pin 3.5mm Plug, DC5.5*2.1mm
	Micro SD Card Slot,
配键型	九轴陀螺仪
传输分辨率	1080p60fps, 720p60fps
图传码率	最大 50 Mbps
最低延迟	中频30ms
天线增益	4.9dBi
天线极化	左旋圆极化 LHCP
传输距离	> 4km
频道	3
屏幕分辨率	1920*1080/60Hz
屏幕材质	LCD
屏幕尺寸	4.5 Inch
电池输入	6V-25.2V(2S-6S)
SD卡槽	支持256G
系统	Avatar HD system

CADDXFPV 技术支持
email: support@caddxfpv.com